

Manual, Assembly instruction: Brodit 853661

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame. Peel off the cover of the adhesive tape on the ProClip.
2. Press the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the control panel and the dashboard. Press the right end of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.