

Manual, Assembly instruction: Brodit 853663

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame. Peel off the adhesive tape covers on the ProClip. Press the upper part of the ProClip into the upper part of the air vent.
2. Press forwards on the lower part of the ProClip and hook the lower edge into the gap next to the gap opener. Pull out the gap opener.
3. Place your fingers "inside" the ProClip and press the lower part towards the frame so the adhesive tape attaches. Pull out the gap opener.
4. The ProClip is in place.