

Manual, Assembly instruction: Brodit 853665

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the enclosed gap opener along the outside of the ProClip and press the thin end into the gap between the center console edge panel frame and the padded part of the dashboard, to widen the gap. While widening the gap with the gap opener: press firmly forward on the left side of ProClip so the angled edge goes into the gap and snaps behind the panel edge. Pull out the gap opener.

2. Place your finger underneath the ProClip and push it upwards, towards the air vent. Support the ProClip with your other hand. Stop when the lower part of the face plate aligns with the upper part of the FM button.

3. Place your thumbs on the left side of the ProClip and your finger in the groove between the panel sections and firmly press/push the ProClip towards the stereo so the angled edge on the right side snaps over the console edge and into the gap.

4. The ProClip is in place.