

Manual, Assembly instruction: Brodit 853666

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Place the ProClip over the frame surrounding the control panel. Press the left end of the ProClip into the gap between the control panel and the surrounding frame.

2. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, press it into the gap in the same place as the ProClip (as shown in picture). Press forwards on the right side of the ProClip so the angled edge hooks into the gap. Pull out the gap opener.

3. Press forwards on the right side of the ProClip until you hear/feel it snaps into place.

4. The ProClip is in place.