

Manual, Assembly instruction: Brodit 853667

Center mount ONLY for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the wood grain panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the lower part of the ProClip into the gap between the wood grain panel and the dashboard.
3. Press forwards on the ProClip so the angled edge on the upper part hooks into the gap between the gap openers. Pull out the gap openers. Press downwards on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.