

Manual, Assembly instruction: Brodit 853668

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the wood grain panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap between the wood grain panel and the dashboard.
2. Press forwards on the ProClip so the angled edge on the upper part hooks into the gap next to the gap opener.
3. Press downwards on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.