

Manual, Assembly instruction: Brodit 853670

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Loosen the screw in the upper left corner of the glove compartment. Press the thin end of the enclosed gap opener into the gap between the glove compartment and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Slide the ProClip upwards in the gap, as far as possible. Pull out the gap opener.

3. Press the gap opener into the gap between the control panel and the surrounding frame. Press the angled edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener. Press forwards on the left side of the ProClip so the adhesive tape attaches. Retighten the screw.

4. The ProClip is in place.