

Manual, Assembly instruction: Brodit 853674

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE! It is very important to place the ProClip exactly as shown in the pictures. Part 1. Attaching part (the smallest part)
Part 2. ProClip face plate.

1. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on Part 1 into the gap between the control panel and the surrounding frame.

2. Press part 1 away from the steering wheel so the angled edge hooks behind the control panel. Press forwards on the right side so the adhesive tape attaches.

3. Open up the predrilled holes in Part 2. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.