

Manual, Assembly instruction: Brodit 853676

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Hook the upper part of the ProClip into the upper part of the air vent.
2. Press the lower part of the ProClip into the gap between the air vent and the surrounding frame.
3. Press forwards on the ProClip.
4. The ProClip is in place.