

Manual, Assembly instruction: Brodit 853677

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Open the glove compartment.
2. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard.
3. Hook the angled edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.