

Manual, Assembly instruction: Brodit 853680

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the padded dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Place the angled edge on the lower part of the ProClip underneath the air vent panel frame.
3. Press firmly forward on the upper part of the ProClip, with your thumb, so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Then press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.