

Manual, Assembly instruction: Brodit 853681

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the climate control panel frame and the padded part of the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the vertical grooved edge into the gap above the Gap Opener (Spaltöffner). Start by pressing forward on the lower part of the ProClip.
3. Press firmly forward on the upper part of the ProClip, with your thumb, so the rest of the grooved edge goes into the gap. Press until you see or hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.