

Manual, Assembly instruction: Brodit 853684

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip fits both silver grey and wood grain trim, and fits within the width of the air vents. You can also attach two next to each other.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the dashboard ledge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the padded dashboard, to widen the gap. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.