

Manual, Assembly instruction: Brodit 853685

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip fits both silver grey and wood grain trim.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the console edge, to widen the gap. Peel off the cover of the adhesive tape on Part 1.

2. Place Part 1 in the same position as in the picture, in the same height. Press the angled edge firmly into the gap above the gap opener and at the same time: bend Part 1 to the right until you hear/feel it snaps into place and the adhesive tape attaches to the console edge.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side attaching to the center console panel frame. Screw Part 2 onto Part 1 using the enclosed screws. When screwing in the lower screw press Part 2 to the right with your thumb for best possible alignment.

4. The ProClip is in place.