

Manual, Assembly instruction: Brodit 853686

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip fits within the width of the stereo. You can also attach two next to each other.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the stereo and the surrounding panel frame.

2. Slide the ProClip all the way to the left.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap in the dashboard. Press down on top of the ProClip to make sure the angled edge is all the way into the gap.

4. The ProClip is in place.