

Manual, Assembly instruction: Brodit 853700

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console panel frame and the console sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook + press the angled edge on the right side of the ProClip into the gap below the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
3. Press the Gap Opener (Spaltöffner) into the gap between the center console panel frame and the stereo. Press firmly forward on the left side of the ProClip the grooved edge goes into the gap below the Gap Opener (Spaltöffner). Press until you see or hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.