

Manual, Assembly instruction: Brodit 853701

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip fits within the width of the center dashboard area. You can also attach two or more next to each other.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard to widen it. Peel off the cover of adhesive tape on the ProClip.

2. Place/hook the angled edge on the lower part of the ProClip under the dashboard overhang.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.