

Manual, Assembly instruction: Brodit 853702

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the two enclosed gap openers into the gap between the air vent panel frame and the center console panel, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Place/press the angled edge on the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.

2. Press one of the gap openers into the gap between the air vent panel frame and the dashboard. At the same time flip the ProClip upwards, towards the top of the air vent, and press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener.

3. Place your hand over the ProClip and press forward and down to make sure the angled edges are all the way into the gaps. Pull out the gap opener.

4. The ProClip is in place.