

Manual, Assembly instruction: Brodit 853704

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the dashboard and center console panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Place/hook the angled edge on the lower part of the ProClip into the upper part of the air vent.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap between the gap openers. Press until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.