

Manual, Assembly instruction: Brodit 853705

Angled mount NOT for use with factory navigation screen



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be positioned anywhere within the width of the center dash compartment box. Fits models with and without wood grain trim.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the compartment bottom/floor and the surrounding panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Slide the ProClip all the way over to the left/right unless you prefer to keep it in a center position.

3. Place your fingers around the ProClip and pull so the ProClip flexes slightly towards you. Then hook/press it into the seam between the climate control panel and the surrounding panel frame. Pull out the gap opener.

4. The ProClip is in place.