

Manual, Assembly instruction: Brodit 853712

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Take a firm grip of the panel over the display and pull it out about 5 mm. In the same time press the curved edge on the right part of the ProClip into the gap that now is widened, between the panel surrounding the panel and the air vent frame. Flip the ProClip towards the steering wheel so the curved right edge hooks behind the panel surrounding the display.

3. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener. Press the panel surrounding the display back into place.

4. The ProClip is in place.