

Manual, Assembly instruction: Brodit 853714

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the control panel and the dashboard. Press the lower part of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.