

Manual, Assembly instruction: Brodit 853715

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on part 1 into the gap between the control panel and the surrounding frame.

2. Press Part 1 rightwards so the angled edge hooks behind the control panel and the adhesive tape attaches to the surrounding frame.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match up and the adhesive tape on Part 2 is on the left side. Screw Part 2 onto Part 1 using the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.