

Manual, Assembly instruction: Brodit 853716

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the stereo and the surrounding panel.
2. Press forwards on the ProClip and hook the angled upper edge into the gap next to the gap opener.
3. Press downwards on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place