

Manual, Assembly instruction: Brodit 853717

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the left part of the ProClip into the gap above the gap opener.
2. Flip the ProClip rightwards so the curved left edge hooks behind the control panel. Pull out the gap opener. Press the gap opener into the gap between the center console and the dashboard.
3. Press the right end of the ProClip slightly against the center console sidewall, in the same time slide/press the ProClip upwards so the right edge goes into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.