

Manual, Assembly instruction: Brodit 853722

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part over the lower edge of the coin compartment.
2. Hook the angled edge on the lower part of the ProClip into the gap in the dashboard.
3. Press on the ProClip so the adhesive tapes attach.
4. The ProClip is in place.