

Manual, Assembly instruction: Brodit 853731

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts Part 1. Attaching part (the smallest part) Part 2. ProClip face plate.

1. Use the enclosed alcohol pad to clean the surface of the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Press the angled edge on Part 1 into the gap between the dashboard and the frame surrounding the control panel.

2. Press Part 1 towards the steering wheel so the angled edge hooks behind the frame surrounding the control panel.

3. Open up the predrilled holes in part with a screwdriver (Philips). Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.