

Manual, Assembly instruction: Brodit 853732

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame, to widen the gap. Use the enclosed alcohol pad to clean the surface where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the upper part of the ProClip into the upper part of the air vent.
2. Press the lower part of the ProClip upwards/forwards so it hooks into the gap next to the gap opener.
3. Press downwards on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.