

Manual, Assembly instruction: Brodit 853733

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console and the panel surrounding the gear shift, to widen the gap. Use the enclosed alcohol pad to clean the surface where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the control panel and the dashboard. Flip the ProClip downwards so the angled upper edge hooks behind the frame surrounding the control panel.

3. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.