

Manual, Assembly instruction: Brodit 853737

Center mount ONLY for models with factory navigation. ONLY for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the wood grain trim and the center console panel, to widen the gap. When you do this the wood grain trim will flex upwards a few millimeters, which is OK. Peel off the cover of adhesive tape on the ProClip.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the wood grain trim and the dashboard ledge. Press forward on the top part of the gap opener, to widen the gap even more. At the same time: press forward on the upper part of the ProClip, and then down on the edge of the ProClip, so the angled edge goes into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.