

Manual, Assembly instruction: Brodit 853738

Angled mount ONLY for models with factory navigation. ONLY for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the wood grain trim and the frame surrounding the climate control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers. Press until you see or hear/feel it click into place. Pull out the gap openers.

2. Press a gap opener firmly into the gap between the wood grain trim and the dashboard ledge, to widen the gap. Press forward on the ProClip so the angled upper edge hooks into the gap. Press firmly down on the top left corner of the ProClip to make sure the angled edge is all the way into the gap. Press until you see or hear/feel it click into place.

3. Press firmly down on the top right corner of the ProClip to make sure the angled edge is all the way into the gap. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.