

Manual, Assembly instruction: Brodit 853742

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap.
2. Hook the angled edge on the right part of the ProClip behind the edge of the dashboard.
3. Pull the ProClip towards you and hook the angled left edge into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.