

Manual, Assembly instruction: Brodit 853743

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of one of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip into the gap next to the gap opener. Flip the ProClip upwards/forwards so the lower edge hooks behind the control panel. Pull out the gap opener.
3. Press both gap openers into the gap on top of the dashboard. Press forwards on the ProClip so the long upper part goes into the gap between the gap openers. Press downwards on the upper edge of the ProClip so it goes all the way into the gap. Pull out the gap openers.
4. The ProClip is in place.