

Manual, Assembly instruction: Brodit 853744

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the curved edge on the left part of the ProClip into the gap above the gap opener.

2. Flip the ProClip rightwards/forwards so the curved left edge hooks behind the control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the control panel and the dashboard. Press forwards on the right side of the ProClip so the angled edge on the right part of the ProClip hooks into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.