

Manual, Assembly instruction: Brodit 853745

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Flip the ProClip upwards/forwards so the angled lower edge hooks behind the stereo. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the frame surrounding the control panel. Press the upper edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.