

Manual, Assembly instruction: Brodit 853746

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the gap opener into the gap between the control panel and the dashboard, to widen the gap opener. Peel off the cover of the adhesive tape on the ProClip.

2. Press the curved edge on the left part of the ProClip into the gap below the gap opener. Press the ProClip rightwards/forwards so the curved left edge hooks behind the control panel. Pull out the gap opener.

3. Press the gap opener into the gap in the dashboard sidewall. Press forwards on the right side of the ProClip so the angled right edge hooks into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.