

Manual, Assembly instruction: Brodit 853747

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the control panel. Peel off the cover of the adhesive tape on the ProClip.

2. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener. Flip the ProClip towards you/downwards so the curved upper edge hooks behind the dashboard. Pull out the gap opener.

3. Pull the ProClip towards you, in the same time press downwards so the angled edge on the lower part of the ProClip hooks into the upper part of the air vent.

4. The ProClip is in place.