

Manual, Assembly instruction: Brodit 853750

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the stereo and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Flip the ProClip upwards + forwards so the angled lower edge hooks behind the stereo. Pull out the Gap Opener (Spaltöffner).

3. Press forwards on the ProClip so the angled edge on the upper part goes into the gap below the display. Press downwards on top of the ProClip so the upper edge goes all the way into the gap.

4. The ProClip is in place.