

## Manual, Assembly instruction: Brodit 853753

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.**

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Place the upper edge of the ProClip into the upper part of the air vent and press upwards so the adhesive tape attaches.
3. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.