

Manual, Assembly instruction: Brodit 853754

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the center console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the right part of the ProClip into the gap above the gap opener. Press firmly so the edge goes into the gap.

2. Flip the ProClip leftwards so the right curved edge hooks behind the dashboard.

3. Hook the angled edge on the left part of the ProClip into the gap in the center console frame. Press the part edge towards the center console frame so the angled edge goes all the way into the gap and the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.