

Manual, Assembly instruction: Brodit 853755

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the long right part of the ProClip behind the edge of the center console side wall.
2. Pull the ProClip towards you/leftwards so the angled edge on the left part hooks over the center console frame.
3. Press the left edge of the ProClip towards the center console frame so it hooks into place properly and the adhesive tape attaches.
4. The ProClip is in place.