

Manual, Assembly instruction: Brodit 853799

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip exactly as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip upwards/forwards so the curved lower edge hooks behind the control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the air vent frame and the dashboard. Press forwards on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press downwards on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.