

## Manual, Assembly instruction: Brodit 853815

Center mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding frame. to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the gap opener downwards into the gap so the gap is wider, in the same time press a corner of the angled edge on the upper part of the ProClip into the gap next to the gap opener. Follow through and press all of the angled edge into the gap. Pull out the gap opener.
3. Pull the ProClip towards you/downwards to keep the adhesive tape from attaching, then hook the angled edge on the lower part of the ProClip under the edge of the dashboard.
4. The ProClip is in place.