

Manual, Assembly instruction: Brodit 853816

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the grooved edge on the left part of the ProClip into the gap above the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the control panel and the dashboard. Press forwards on the right side of the ProClip so the angled edge on the right part snaps into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.