

Manual, Assembly instruction: Brodit 853825

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the dashboard ledge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the air vent panel frame and the padded part of the dashboard. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.