

Manual, Assembly instruction: Brodit 853826

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the thin edge on the upper part of the ProClip into the air vent.
2. Place your thumb underneath the ProClip and press firmly upwards and insert it into the air vent.
3. Release the pressure and insert the angled edge down into the seam/gap between the air vent and the surrounding panel frame.
4. The ProClip is in place.