

Manual, Assembly instruction: Brodit 853831

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the air vent panel frame and the stereo, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.
3. Press firmly down on top of the ProClip and insert the thin end into the air vent so it is attaching to the upper inside part of the air vent.
4. The ProClip is in place.