

Manual, Assembly instruction: Brodit 853832

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the dashboard overhang, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap in the panel sections next to the glove compartment.

3. Flip the ProClip upwards and steer the upper edge towards the gap next to the gap opener. Place your fingers as shown in the picture and press the ProClip firmly upwards/forward so the grooved edge snaps into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.