

Manual, Assembly instruction: Brodit 853837

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip into the upper part of the air vent. **2** och **3.** Place your thumb onto the top part of the ProClip. Press firmly forward on the ProClip so the angled edge goes into the gap in the dashboard. Press until you see or hear + feel it snaps into place.

4. The ProClip is in place.