

Manual, Assembly instruction: Brodit 853838

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Open the glove compartment door. Press the angled edge on the upper part of the ProClip into the gap in the dashboard ledge.
2. Press firmly forward on the lower part of the ProClip so the angled edge hooks under the dashboard edge. Press until you see or hear/feel it snaps into place.
3. Press firmly upwards on the ProClip to make sure it is properly attached. Close the glove compartment door.
4. The ProClip is in place.